

PKHPMAXMulti-Frame Heat Pump Unit Pipe Kit



These kits are braze-free alternative to the equipment manufacturer Outdoor Unit Multi Connection Pipe Kits. These outdoor pipe kits provide the necessary Y-Branch fittings, couplings, reducers, to field connect dual and triple frame VRF outdoor units to the refrigerant tubing system by means of permanent mechanical connection. Each kit is custom built to match the project system selection lay-out as provided by the customer.

The Y-branch, couplings, reducers, and silicone cold shrink sleeves are shipped loose for installation on to the field piping. Accessory tubing and outdoor unit connectors are NOT included and must be installed separately.

All RCS fittings installed outdoors, at the outdoor units, on insulated piping located outdoors, in wet/humid environments, or wherever the thermal insulation cannot be installed per the insulation manufacturer's instructions, must be protected from possible corrosion via the use of cold shrink, heat shrink, or other suitable impervious protective cover.

Refer to RCS installation instructions for details prior to installation.

*The copper Y-Branch center fittings are not UL Listed component.

Application High Pressure HVAC/R

Max Rated Pressure 600 psi

Compatible Tubing Seamless Copper Tubing, Drawn H58, Light Drawn H55, or Annealed O60 made to ASTM B280

and ASTM B75 Standard.

Agency Approval ETL Listed 5011885. Conforms to UL 207 STD. Certified to CSA STD C22.2#140.3

Refrigerants All CFC, HCFC, HFO, and class A2L refrigerants and refrigeration oils.

The product is suitable for use with R744 (CO2) when used within the design pressure rating.

The product is not suitable for use with ammonia, methyl chloride, hazardous or flammable

refrigerants from Group 2 or 3 per ASHRAE 15.

Installation The fittings must be installed per RCS installation instructions by skilled installers, trained


specifically in the application and installation of RCS fittings.

DUAL FRAME HEAT PUMP	TRIPLE FRAME HEAT PUMP
PKHPMA2-N21A-XXX	PKHPMA3-N31B-XXX
PKHPMA2-P100-XXX	PKHPMA3-P151-XXX
PKHPMA2-21SA-XXX	PKHPMA3-30SA-XXX

Assembly Guide


Tube surface must be clean, free from scratches or any surface imperfections, and de-burred inside and out.

Place tube support INSERT in to clean and de-burred tube.




Place Fitting onto Tube with INSERT until
TUBE/INSERT contacts the inner stop.

Mark Tube at end of FITTING with permanent felt tip marker.




Apply LocTite® to full circumference of tube end. Keep LocTite® 1/8" from end of TUBE and INSERT.


3



Keeping the TUBE/INSERT against the FITTING inner stop, slide the COLLAR against the FITTING. Collar should overlap the FITTING body.




Place the FITTING and COLLAR into correct size press clamps. The assembly MUST be fully seated on the lower circumference of the clamps. Do not change the insertion depth of the TUBE/ INSERT and the connecting joint.



6

Using the press tool, press the COLLAR onto the FITTING body until it is fully seated against FITTING stop. TUBE/INSERT must be maintained against the FITTING inner stop during the pressing operation.





That the tube insert depth reference mark is visible and closely aligned with the end of the FITTING body.



That the COLLAR is in the correct orientation, fully seated, and is flush against the shoulder of the FITTING body.



That any gap between the COLLAR and the FITTING shoulders are less than 1mm.

8